

## BATTERY CARE TIPS

IMPORTANT BATTERY STORAGE, HANDLING AND CARE TIPS

# MOTOROLA SOLUTIONS RECOMMENDATIONS FOR NEW BATTERY USE, STORAGE AND CARE

## IMPORTANT BATTERY STORAGE, HANDLING AND CARE TIPS – PLEASE READ

Battery capacity naturally decreases slowly over time and the MSI battery warranty begins when the battery is shipped, thus to take full advantage of your new battery's capacity and warranty, use batteries promptly after purchase.

Always charge your battery using the approved Motorola charger. Charging in non-Motorola chargers may lead to reduced performance and battery damage.

If you need to store your new batteries prior to use, please be aware that proper storage guidelines and time durations must be followed.

1. Do not store batteries with flammable materials.
2. Remove battery from radio to eliminate radio as a source of additional current drain. Do not replace the battery in any area labeled "Hazardous Atmosphere".
3. Store batteries in a well ventilated, temperature (68°F/20°C to 86°F/30°C) and humidity (30%-60%) controlled environment.
4. Optimal battery storage condition is 30%-50% charge state. Used batteries should be charged or discharged to approx 50%.\*
5. Batteries removed from storage may take several charge / discharge cycles to achieve their optimal capacity. One or two reconditioning cycles will accelerate capacity recovery.
6. Use the battery in accordance with its water and dust Ingress Protection (IP) rating.
7. Don't disassemble, crush, puncture, shred, or otherwise change the form of your battery. Don't discard your battery in a fire.
8. Don't dry a wet battery with an appliance or heat source, such as a hair dryer or microwave oven. If the radio battery contacts are wet, dry the battery contacts before attaching the battery to the radio.
9. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects such as jewelry, keys or coins.

10. For IMPRES batteries, the first battery charge should take place in an IMPRES desktop (not vehicular) charger for proper initialization of IMPRES data in battery memory. Allow the battery to be fully charged through a solid green LED charger status indication.

The batteries listed below contain additional active circuitry required to meet specific regulatory requirements. This circuitry increases the rate of self discharge. For best performance these batteries should be used within 1 month of receipt. However, if storage is required, the batteries should be charged to a 30% charge state every 3 months.

### Active Circuitry Batteries

NNTN8840	Battery Li-Ion Intrinsically Safe IECEx/ATEX
NNTN8570	Battery Li-Ion Intrinsically Safe IECEx/ATEX
NNTN8750	Battery Li-Ion Intrinsically Safe CSA, and IECx/ATEX
NNTN8287	Battery Li-Ion IMPRES Intrinsically Safe CSA
NNTN8386	Battery Li-Ion IMPRES Intrinsically Safe CSA
NNTN8359	Battery Li-Ion IMPRES Intrinsically Safe IECEx/ATEX
NNTN5510	Battery Li-Ion Intrinsically Safe IECEx/ATEX
NNTN7383	Battery Li-Ion Intrinsically Safe IECEx/ATEX
PMNN4547A	Battery Li-Ion IMPRES Intrinsically Safe TIA4950 Div1 / Div2

\*The new International Air transport Association (IATA) policy requires batteries to be shipped in bulk, by air at a state of charge of no more than 30% of their rated capacity.



Motorola Solutions, Inc. 500 West Monroe Street, Chicago, IL 60661 U.S.A. [motorolasolutions.com](http://motorolasolutions.com)

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2017 Motorola Solutions, Inc. All rights reserved. 12-2017